



HIGH FENCE

Notes:

1. Make one from $\frac{3}{4}$ " stock.
2. Drill all holes to clear a 1/4-20 bolt.

