



SLIDER

Notes:

1. Make one from solid hardwood stock.
2. Install 1/4-20 threaded inserts or T-nuts at all three locations marked "A". If using T-nuts, counterbore around them so they sit flush with the surrounding surface.
3. Drill the hole at B to accommodate the screw used to attach the rail protector to the slider.

